CZ

P-10 C OR
CALIFORNIA COMPLIANT

Disassembly Instructions

1. **MAKE SURE THAT YOUR WORK AREA IS CLEAR OF ANY AMMUNITION.**
2. **POINT YOUR PISTOL IN A SAFE DIRECTION.**
3. Remove the magazine from the pistol.
4. **BE SURE NONE OF YOUR CZ P-10 MAGAZINES CONTAIN ANY AMMUNITION.**
5. Pull the pistol slide back and verify there is no round in the chamber.
6. Allow the slide to go forward in the normal firing position.
7. Insert any **EMPTY** magazine into the pistol.
8. Point the pistol in a safe direction and pull the trigger. Make sure the trigger remains in the rear position.
9. Remove the magazine. **THE PISTOL MUST NOT BE DISASSEMBLED WITH THE MAGAZINE INSERTED.**
10. Grasp the frame with your palm, using the fingers of the same hand to grasp the rear part of the slide from the top. Use your fingers to move the slide back no more than 5mm. See Figure 7 of the instruction manual.
11. Use the fingers of your other hand to push the disassembly plate downwards until it stops. (Fig. 8).
12. Release the pressure on the slide and remove it from the frame (Fig. 9).
13. Remove the recoil spring from the slide and finally the barrel.

Note: Before reassembling the slide on the frame, the trigger must be pulled to the rear position to prevent the frame from colliding with the protrusion on the trigger bar. No further disassembly is needed for routine maintenance.

Scan the QR Code below for a video demonstration of the disassembly and assembly process.